



AIR & WATER Home Environment Centre Inc.

260F Broadway Avenue North Williams Lake, BC V2G 2X9

Business (250) 392-4440 Fax (250) 392-4438

Aug/2000

To Sanitize your Reverse Osmosis System

- Drain off all water from Reverse Osmosis holding tank via tap at sink
- Turn off feed water and tap at RO pressure tank
- Remove all filter elements
- Remove membrane
- Put system sumps back together, but add 2-3 tbsp of house-hold bleach into first sump
- Open feed water tap and holding tank taps
- As soon as you can smell bleach at sink tap turn off sink tap
- Turn off feed water tap
- Allow system to sit for at least ½ an hour.
- Drain off RO holding tank at sink tap
- Remove all sumps and membrane end clip, being very careful as not to spill the water with bleach onto your clothes or cabinets
- Once all are emptied, replace the filter elements as per order and load membrane into chamber, remember that the membrane has a seal at the end close to the loading side when installed(the twin O-Rings at the other end of the membrane should be at the bottom of the membrane sump)
- Once all are sealed turn on tap on RO holding tank and feed water
- Remember to dump the first two full tanks of water before using as they will contain a sanitizing solution from the membrane. Just open the sink tap until all is gone
- Let your taste buds be the judge, as the sanitizing solution will have a “clinical” taste, if unsure dump one more tank